

**Electronic Lock Operating Instructions**  
**-LG Safe Guard Lock with Combination Lock Back Up-**  
**Vault Doors**

**Operating Instructions**

- Enter combination on the keypad *Lock will signal when proper combination has been entered*
- Turn combination dial one turn clockwise until dial stops
- Turn safe handle

**\*Repeated beeping during an opening indicates that the Battery is low and should be replaced**

\*Invalid combination entry: Lock signals three times

\*Wrong try penalty entry of three consecutive invalid combinations will initiate a 5 minute lock out period, during which time the LED flashes red at 10 second intervals

**Changing Combination**

*(Lock signals twice after each valid entry)*

\*Change combination with door open\*

- Enter six zeros
- Enter existing combination
- Enter new six digit combination **TWICE**

**\*Before closing door\***

Enter existing combination to verify proper operation

**Changing Batteries**

- Remove keypad by gently lifting straight up and tilting back
- Please note keypad cable only has a few inches of free length
- Connect one 9-Volt Alkaline battery (Duracell only) to each battery clip
- Insert batteries into bottom of housing
- Replace by placing the keypad on its mounting pins and sliding down until keypad is firmly locked into position